

HOW TO ASSEMBLE









ZENITH
3.06 x 3.60m (10ft)










IMPORTANT!

Please read these instructions carefully before starting assembly.
Keep these instructions in a safe place for future reference.



AVAILABLE MODELS


10x12 / 3x3.7		10x16 / 3x5		10x20 / 3x6	
					
PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 	PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 	PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 
		1 EXT. UNIT 10x4 / 3x1.2	1 BOX 	2 EXT. UNIT 10x4 / 3x1.2	2 BOXES 

10x24 / 3x7.2		10x28 / 3x8.5		10x32 / 3x9.6	
					
PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 	PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 	PRIMARY UNIT 10x12 / 3x3.7	2 BOXES 
3 EXT. UNIT 10x4 / 3x1.2	3 BOXES 	4 EXT. UNIT 10x4 / 3x1.2	4 BOXES 	5 EXT. UNIT 10x4 / 3x1.2	5 BOXES 


BASE DIMENSIONS BALANCE SERIES

MODELS	WIDTH
10x12 / 3x3.7	A 304 cm / 10'
10x16 / 3x5	
10x20 / 3x6	
10x24 / 3x7.2	
10x28 / 3x8.5	
10x32 / 3x9.6	

LENGTH	EXTENSION UNITS
B	-
	120 cm / 4' (x1)
	120 cm / 4' (x2)
	120 cm / 4' (x3)
	120 cm / 4' (x4)
	120 cm / 4' (x5)




TOOLS & EQUIPMENT




☐ 2 people needed




☐ Work gloves




☐ Spirit Level




☐ Electric Drill
With Drill Bit
10 mm | 3/8"



☐ Philips head
Screwdriver



☐ Rubber
Mallet




☐ Wrench
7 mm | 1/4"
10 mm | 3/8"




☐ Lubricant
Spray



☐ Cordless drill
Phillips head



☐ Tape measure



☐ Ladder

SITE PREPARATION & FOUNDATION



A - PREPARE THE SITE

The product must be positioned and fixed on a flat level surface.

① - Clear the site





② - Level the ground





B - CHOOSE YOUR FOUNDATION TYPE

For a foundation, we recommend using three material types :
Concrete / Pressure treated wood / wood deck / Paver blocks


Option 1: Solid foundation



Option 2: Solid frame



Option 3: Firm ground / grass




* The size of the product displayed is for illustration purposes only and may not reflect the size of your product.


C - ANCHOR TO FOUNDATION

3 options to anchoring the product to the foundation of your choice.


Internal anchoring



Supplied



Supplied




Not supplied

External anchoring

①


Secure the product to the foundation of your choice using suitable screws & plugs or masonry anchors.



Supplied

②


Make sure you have at least 5 cm / 2" between the product base and the edges of your foundation - on all sides.



Supplied

③

Secure the product to the ground surface using suitable long pegs.



Supplied

* Please consult with an expert regarding which fasteners are suitable for other surface types.

SAFETY ADVICE

- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any steps.
- Always wear work gloves during panel sliding.
- Always wear shoes and safety goggles when working with extruded aluminium.
- If using a step ladder or power tools make sure that you follow the manufacturer's safety advice.
- Do not touch overhead power cables with the aluminium profiles.
- Do not attempt to assemble the product in windy or wet conditions.
- Do not climb or stand on the roof.
- Dispose of all plastic bags. Keep them out of reach of small children.
- Keep children away from the assembly area.
- Do not lean against or push the products during construction.
- Do not position your product in an area exposed to excessive winds.
- Do not attempt to assemble this product if you are tired, have taken drugs or alcohol or if you are prone to dizzy spells.
- Hot items such as recently used grills, blowtorches etc. must not be stored in the product.
- Make sure there are no hidden pipes or cables in the ground before anchoring to foundation.
- Keep roof and gutters clear of snow, dirt & leaves.
- In strong winds, all openings and the door should be closed. Greenhouse roofs should be cleared of snow in good time so that no dangerous snow load can occur.
- This product is designed to be used mainly as a greenhouse.
- **⚠ Make sure to anchor the product directly to a solid foundation to increase the product's stability and wind resistance in areas with severe weather conditions. Make sure that there are no obstructions between the assembly area and the final position of the product. The Canopia Anchoring kit is available for purchase separately.**

CARE & MAINTENANCE

- When your product needs to be cleaned, use a soft cloth and rinse with cold clean water.
- DO NOT use acetone, abrasive cleaners or other special detergents to clean the panels.
- Clean the product once assembly is complete.

BEFORE ASSEMBLY


- Selecting a site:
 - Choose your site carefully before beginning assembly.
 - Choose a sunny position away from overhanging trees.
 - The product must be positioned and fixed on a flat level surface.
- The product must be secured directly to a solid foundation.
- This is a multi-part assembly best achieved by two people. Allow at least half a day for the assembly process.
- Take all components & parts out of the packages. Sort the parts and check against the content parts list.
- Parts should be laid out close at hand. Keep all small parts (screws etc.) in a bowl so they do not get lost.
- Please note multi-sided profiles are used in this product. As a result some holes in the profiles are not used during assembly.
- Please review entire instructions before starting. Carry out the assembly steps in exact order.
- Please consult your local authorities if any permits are required prior to constructing the product.
- Please ensure you have sufficient side space for inserting the roof panels during the assembly process.

IMPORTANT!


- **Firmly connect the product to a level surface immediately after completion of the assembly.**
- **Anchoring this product to the ground is essential to its stability and rigidity. It is required to complete this stage in order for your warranty to be valid.**
- **During assembly use a soft surface below the parts to avoid scratches and damages.**
- **We recommend checking for restrictions or covenants for building this product in your area.**
In addition we advise to check if you need to submit any forms or if any permit is required prior to building the product.

DURING ASSEMBLY

During assembly, you will encounter different icons for different products. Please see below for more information:



Make sure you remove covering plastic film from both sides of the panel.



All panels with the stamped words "THIS SIDE OUT" must be facing out to create full UV protection. Remove plastic sticker as panels are locked in place.




This icon indicates that the installer should be inside the product.



This icon indicates that the installer should be outside the product.



Steps marked with dashed outlines refer to Extensions only. Some of the steps are irrelevant for an assembly of a single product. When assembling a single or an extended product, some parts may be surplus.



These 2 icons below indicate if screw's tightening is required or not.

Temporary tightening of a few screws may be needed to prevent a profile from sliding out.

Tighten all screws once assembly is completed.



IMPORTANT ASSEMBLY STEPS

When encountering this information icon during assembly, please refer the relevant assembly step for important additional comments.

- Step 3:** Refers only to the extension kit!
The extension kit contains a base connector, part **#8447**.
- Steps 33, 44:** Refers only to the extension kit!
Use the profile **AS9845** (prepared in **Step 25**) for installation of the window in the extension kit.
- Step 56:** When assembling the Extension kit, the installation direction of part **#9935** is crucial.
Make sure the side marked with the arrow in the closeup diagram is facing the direction of the window.
- Step 65:** Refers only to the extension kit!
Assemble the window by threading below part **#9935**.
Use a screwdriver to assist with inserting the rubber part **#7009** into the profile.
- Step 68:** If the window doesn't close properly, please release the screws, adjust the profile and re-tighten the screws.
- Step 69:** If you have an "Auto Vent Opener" you should refer to its assembly instructions on the website: canopia.shop/vopener
- Step 88:** Make sure the cable is threaded in the hole (**#7327**) and does not interfere with the window's opening.
- Step 89:** Anchor the greenhouse to the solid foundation or frame by using part **#7331**.
Anchor the greenhouse to firm ground or grass by using part **#7336**.
- Step 91:** Stretch the cable by using part **#7332**.




















PRINCIPALES ÉTAPES D'ASSEMBLAGE











Lorsque vous rencontrez cette icône d'information pendant l'assemblage, veuillez vous référer à l'étape d'assemblage correspondante pour d'autres commentaires importants.

- Étape 3:** Ne concerne que le kit d'extension !
Le kit d'extension contient un connecteur de base, pièce **#8447**.
- Étapes 33, 44:** Ne concerne que le kit d'extension !
Utilisez le profil **AS9845** (préparé à l'étape 25) pour monter la fenêtre dans le kit d'extension.
- Étape 56:** Lors de l'assemblage du kit d'extension, le sens de montage de la pièce **#9935** est crucial.
Veuillez à ce que le côté indiqué par la flèche dans le gros plan soit orienté dans la direction de la fenêtre.
- Étape 65:** Ne concerne que le kit d'extension !
Montez la fenêtre en la passant sous la pièce **#9935**.
Utilisez un tournevis pour faciliter l'insertion de la pièce en caoutchouc **#7009** dans le profilé.
- Étape 68:** Dans le cas où la fenêtre ne ferme pas correctement, veuillez desserrer les vis, ajuster le profil, et de nouveau resserrer les vis.
- Étape 69:** Si vous avez un "Auto Vent Opener", vous devez vous référer à ses instructions de montage sur le site Web : canopia.shop/vopener
- Étape 88:** Assurer que le câble est enfilé dans le trou (**#7327**) et ne gêne pas l'ouverture de la fenêtre.
- Étape 89:** Fixez la serre à une base ou un cadre solide à l'aide de la pièce **#7331**.
Fixez la serre à un sol solide ou au gazon à l'aide de la pièce **#7336**.
- Étape 91:** Tendez le câble en utilisant pièce **#7332**.







Contents



Item		Qty.
9949		5
9845		10
9855		2
993		10
994		1
995		1
9846		4
972		4
9857		1














Item		Qty.
9863		2
1195		1
8362		1
9427		1
9858		8
9859		4
9848		1
9802		4












Item		Qty.
999		5
9847		4
8549		2
9860		8
9849		1
9850		1
7068		2
983		2
9856		2
7336		4











Contents

Item	Qty.
973 	2
9851 	2
9853 	1
9854 	1
9852 	4
1105 	8

Item	Qty.	Item	Qty.
7332 	2	9227 	5

Item	Qty.
462 	6
464 	12
463 	6
465 	24 (+3)
422 	24 (+3)
7066 	2
8230 	2
7871 	2
7870 	2
9861 	8
7331 	4
9235 	4
7333 	4







Item	Qty.
07 	1
7330 	2
8710 	10
9862 	2
9935 	1
8797 	4
8798 	4
8801 	4
8799 	4
8800 	4
7985 	4

Item	Qty.
8254 	1
8255 	1
7602 	4
8447 	3
343 	2
344R 	2
344L 	2
329 	10
328 	36 (+6)
292 	2



Contents

Item	Qty.	Item	Qty.	Item	Qty.	Item	Qty.
9864	8	991	4	586	4	411	216 (+28)
9865	4	992	8	9873	6	8192	23 (+2)
9867	3	989	4	3017	8	7284	36 (+3)
		990	4	7009	8	410	4
		984	4			466	271 (+17)
Item	Qty.	Item	Qty.	Item	Qty.	412	4 (+12)
9870	1	7011	14	560	2	7442	48 (+5)
9871	1	9866	4	559	2	4008	26 (+2)
9872	1	553	1	9869	1	4045	34 (+3)
				9868	1	450	2
						4000	17
						4010	17
						433	17 (+1)
						7524	4



Contents



Item		Qty.
7083		2
7084		2
7085		2
7086		2
7088		2
423		2

4043		10 (+1)
------	--	------------

7327		2
7271		1

461		8
DO NOT USE		

981		12
318		20

9953		8
4044		8

Contents Extension Kit

Item	Qty.
991	1
992	2
989	1
990	1
981	4
318	6 (+2)
586	1






Item	Qty.
9845	4
993	4
7597 Or 1195	2
977	1
976	2
1123	4
9858	2
9859	1









Item	Qty.
411	54 (+7)
8192	2
7284	9
410	1
466	60 (+8)
412	1
7442	16 (+2)
4008	6 (+1)
4045	12 (+1)
4000	6
4010	6
433	6
7524	2
4043	4

Contents Extension Kit

Item	Qty.	Item	Qty.	Item	Qty.	Item	Qty.
3017	2	7331	2	8797	1	9864	3
7009	2	9235	2	8798	1		
08	2	7333	2	8801	1	9865	1
9935	1	7332	1	8799	1		
8710	2			8800	1	7011	4
8447	2	7336	2	07	1		
7985	4	7327	1				
9860	2	7330	1				
329	4						
328	4 (+2)	9953	2				
292	2	4044	2	461	2		
9861	4			DO NOT USE			

1






Extension Kit


3



The extension kit contains a base connector, part # **8447**




7597 / 1195



.....2

8447









.....2

7442





.....16






$$A=B$$
















7284 8 8192 8 466 16






Extension Kit

7284 +2
8192 +2
466 +4













8192 1










411 3









466 3





10 mm
3/8"
















.....3



.....2







7011 +4
318 +4





x12 +4

AS7011 =



a



















9858	+2
9859	+1
9860	+2
7284	+4
466	+4
4045	+4

x4 +1


AS9858 =
















AS7011.....









.....8









- 08 2
- 292 2
- 4008 2
- 411 4
- 466 4





AS9858





.....2


466




.....4















a




b


























9846.....
















411..........2 466..........2









Extension Kit


9845.....	+2
8710.....	+2
411.....	+4
466.....	+4




AS9845=


x4

+1





AS9845



411







12



466




4




Windows Location





AS973



1

411









2






466




2





28 Extension Kit



29 Extension Kit



976.....



.....2

411.....





.....4


466.....




.....4




a














b




c




30 Extension Kit



31 Extension Kit



AS9858




1




466






2







10 mm
3/8"



32 Extension Kit



AS977 =




Extension Kit


33




Use the profile **AS9845** (prepared in Step 25) for installation of the window in the extension kit.



9845.....



AS9845



411





6

466











2

Windows Location




AS9845





AS977



..... 1

411










..... 8

466



..... 2





- 993





4
- 9802


2
- 7284

4
- 411


8
- 466

8
















AS7011.....




.....4







AS9858





2


466




4




a




b





AS9845



4

411



12




466








4



10 mm
3/8"










411.....  8



466.....  2







a




b







9845



.....2

411.....





.....6

466.....



.....2




Extension Kit


44



Use the profile **AS9845** (prepared in Step 25) for installation of the window in the extension kit.




AS9845 ..



1

9845



3

411





12

466







4







Windows Location




AS9845











10 mm
3/8"







9856..... 2 411..... 2 466..... 4












9866





4






1123	+4
7985	+4
4045	+8




x4

AS1105E =


x4





a









b







AS1105E +2
466 +8





AS1105








466 10













Extension Kit









AS1105E+2


466+8




















411..........6 466..........6








Extension Kit


56 **i** When assembling the Extension kit, the installation direction of part # **9935** is crucial. Make sure the side marked with the arrow in the closeup diagram is facing the direction of the window.














9935..... 1 466..... 4 4045..... 2




 9935..... +1
466 +4



 Extension Kit








- 990  4 411  12 466  8




- 990 +1
411 +3
466 +2




a



b





9865



.....4

981







.....4



9865.....+1



981+1





9864..... +3



318 +3





8

981




8

4043 10



329 10










Extension Kit


AS9864 +3

981 +3




329 +4


4043 +4







4045..........8









586.....4




991.....4




989.....4




411.....12



992.....8





3017.....8





4008.....16


Extension Kit

586	+1
989	+1
991	+1
992	+2
3017	+2
411	+3
4008	+4







7009  8








Extension Kit

65 **i** Assemble the window by threading below part # 9935.
Use a screwdriver to assist with inserting the rubber part # 7009 into the profile.



7009  2





8797.....4

8798.....4

8801.....4

410..........4

412..........4

Extension Kit

8797+1
8798+1
8801+1
410+1
412+1

a

8797

8798

x4

+1

b

8798

8797



8801

410







412

x4

+1




8799+1
8800+1




68






If the window doesn't close properly, please release the screws, adjust the profile and re-tighten the screws.



466 8




466 +2










x4

+1









If you have an "Auto Vent Opener" you should refer to its assembly instructions on the website:
canopia.shop/VOpener











x4




+1











- 464 12
- 465 24
- 422 24





















- 984  2 7066 2 4008 4











411 30










984  2 4008  4












8230	2	7870	2	411	4	466	8
7871	2									














- 7798 2
- 8710 2
- 7065 2
- 466 20











- 7083  2
- 7084  2
- 7085  2
- 7086  2
- 7088  2
- 423  2
- 466  4










462  6




466  12
















463 6





- 344R..........2 344L..........2 343..........2 7442..........4






9861 8

4000 8


4010 8

433 8
M8




Extension Kit



9861 +4
4000 +4
4010 +4
433 +4
















10 mm
13/32"








A=B








7330	+1
9235	+2
7284	+1
7524	+2
466	+2







328 36




328 +4







Make sure the cable is threaded in the hole (# 7327) and does not interfere with the window's opening.



7327






..... 2





Extension Kit

7327 +1







Anchor the greenhouse to the solid foundation or frame by using part # 7331
Anchor the greenhouse to firm ground or grass by using part # 7336




OR



Extension Kit





4000	+2
4010	+2
7331	+2
433	+2
OR		
7336	+2




1







OR

2






OR








Stretch the cable by using part # 7332.



73334





73322



Extension Kit

7332 +1

7333 +2



OR

